



QUIK-SHIELD DRAGON XL

No Mix Open-Cell Foam

QUIK-SHIELD® DRAGON XL is an open-cell spray foam insulation that requires no mixing. It is ideal for high-performance and air barrier insulation applications in residential (IRC) and commercial (IBC) construction. QUIK-SHIELD DRAGON XL is free of emissive catalysts and has excellent adhesion. This is a true no mix product, achieving optimal performance without mixing prior or during application, making it quick and seamless to dial-in.

TYPICAL PHYSICAL PROPERTIES

Properties achieved in a lab environment at 77°F. Field conditions may cause variation in properties.

	PROCEDURE	VALUES
Air Permeance at 1" (L/s.m ²)	E-2178	<0.02
Closed-Cell, content (%)	D-2856	<90
Nominal Density lb/ft ³ (pcf)	D-1622	0.45
Dimensional Stability (%)	D-2126	<15
Tensile Strength lb/in ² (psi)	D-1623	≥3
Flame (FSI) and Smoke (SDI)	E-84	Class 1/ Class A
Water Vapor Permeability (perm-inch)	E-96	1.72
Fungi Resistance	C-1338	No Growth

Thermal Resistance (R-Value) (°F.ft².h/Btu)

R-Value at 1"	3.9
R-Value/inch at ≥ 3.5"	3.7

THERMAL/IGNITION BARRIERS

	PROCEDURE	VALUES
Thermal Barriers ¹	NFPA 286	Pass without an intumescent coating

1. For information on thermal and ignition barriers please refer to DrJ Engineering Technical Evaluation Report # 2310-01 (TER 2310-01)

LIQUID PROPERTIES at 77°F (25°C)

	A-SIDE (ISO)	B-SIDE (RESIN)
Specific Gravity	1.23	1.07
Viscosity (cPs)	200±50	250±50

RECOMMENDED STORAGE AND SHELF LIFE

- Storage temperatures 50-90°F (10-32°C). See back for preconditioning of material.
- 6 month shelf life from date of manufacture (unopened containers)
- Keep container tightly sealed
- Store out of direct sunlight, in a cool dry place, avoid freezing

PRODUCT INFORMATION

LEED QUIK-SHIELD® DRAGON XL has a minimum of 20.1% total renewable/recycle content, 2.2% pre-consumer recycled, 2.9% post-consumer recycled, and 15.0% rapidly renewable.

Product Packaging 55 Gallon Drum

APPROVALS / COMPLIANCE

QUIK-SHIELD® DRAGON XL has been evaluated by a third party laboratory (DrJ Engineering).

DrJ Certification - TER No. 2310-01

GREENGUARD Gold Certified





PREPARATION OF SUBSTRATES

Providing the proper substrate is the responsibility of the owner, the owner's appointed representative, the contractor, and/or inspector. The following are manufacturer's recommendations. However, other preparation techniques may be required given unique/specialized application circumstances. Contact SWD Technical Support at 888-380-2022 for additional questions.

It is recommended to remove dust, dirt, oil, paint, and alternative polymers from all surfaces prior to applying SWD products.

See SWD specifications or SPFA guidelines for further details on substrate prep.

Wood	<ul style="list-style-type: none">• Ensure wood is relatively dry and protect surfaces from contamination. For moisture content exceeding 19%, contact SWD Technical Support.• Water or oil present may cause poor adhesion or excessive foaming.• Fill large voids with appropriate backer rods or appropriate fillers.• If additional information is required, contact SWD Technical Support.
Steel & Other Metals	<ul style="list-style-type: none">• It is the responsibility of the contractor/end user to determine proper adhesion and suitability through field testing. Blasting and/or priming is not always required. If additional information is required, contact SWD Technical Support.
Concrete	<ul style="list-style-type: none">• If applying foam to concrete, the concrete surface should be structurally sound, clean, and curing for 28 days.• Fill large voids with appropriate backer rods or appropriate fillers.• Blasting and/or priming is not always required. It is the responsibility of the contractor/end user to determine proper adhesion and suitability. If additional information is required, contact SWD Technical Support.
Previously Applied Foam or Other Polymers	<ul style="list-style-type: none">• As practical, remove previously applied foam and other polymer products. Application of product over existing materials should be performed only after adhesion/compatibility is verified by the contractor and accepted by the building owner or owner's appointed representative.

PROCESSING

Preconditioning	<ol style="list-style-type: none">1. It is recommended to precondition material to 70-85°F prior to application. Material may thicken at lower temperatures which can cavitate pumps.
Mixing	<ol style="list-style-type: none">2. Mixing of B-Side (resin) is not required.3. Mixing of A-Side (iso) is not required.
Pressure Settings	<ol style="list-style-type: none">4. Product should be sprayed with a high pressure plural-component proportioner capable of a minimum of 1000 psi dynamic pressure.5. Static pressure is typically set between 1300-1500psi.6. Dynamic pressure typically operates at a minimum of 1000psi.
Temperature Settings	<ol style="list-style-type: none">7. Primary heaters and hose heaters are typically set between 115-135°F (46-57°C). Higher temperatures are utilized in winter months, lower temperatures are utilized in summer months.

Proper application temperature setting is the responsibility of the end user. Equipment temperature varies and can be dependent on equipment, hose length, elevation, ambient temperature, substrate temperature, humidity, and other factors. If additional information is required, refer to QUIK-SHIELD DRAGON XL Processing Packet found on swdurethane.com and the SWD mobile app, or contact SWD Technical Support at 888-380-2022.

APPLICATION

1. Clean surfaces according to "Preparation of Substrates" section.
2. If priming, follow manufacturer recommendations. Ensure primer is adequately cured prior to application.
3. It is the contractor's responsibility to determine if ambient and substrate temperatures are conducive for spraying foam.
4. Flush an adequate amount of material through the lines/gun prior to spraying desired surface when changing between systems. Flush amount will be dependent on prior system used. If additional information is required, contact an SWD representative for more details.
5. Before application, test material to ensure that material sprays, cures, and hardens properly.
6. Inspect applied material intermittently to ensure no problems exist. If problems are detected, discontinue application and inspect all substrates, equipment, gun, and liquid material for problem source(s).

CLEANING AND MAINTENANCE

1. Spray equipment must be maintained in proper operating condition. Failure to adequately maintain spray equipment may result in poor product performance. Refer to your equipment manufacturer's maintenance procedures for more details.
2. Contact SWD for long-term equipment storage recommendations.



The information herein is believed to be reliable; however, unknown risks may be present. SWD Urethane makes no warranty, expressed or implied, concerning this product's merchantability or fitness for any particular use. The product will meet the written liquid component specifications as indicated on the technical data sheet published at the time of the purchase. The entirety of SWD Urethane's responsibility is limited only to the cost of the SWD material. The foregoing constitutes SWD Urethane's sole obligation with respect to damages, whether direct, incidental or consequential, resulting from the use or performance of the product.

Safety is the responsibility of the owner, the owner's appointed representative, the contractor, and/or inspector. Become familiar with local, state, and federal regulations regarding chemical health, safety, and handling. For more information consult the product SDS, contact the SPFA (www.sprayfoam.org) or the ACC (www.spraypolyurethane.org).